



Figure 2-9. Electrical Equipment Harness ST-149/PRC-71, with Equipment

anywhere to the wearer's body or tied to the handles on the transceivers. Compartments are provided for headset-microphone, leaf antennas, wire antennas, repeater cable or other accessories.

2-53. MOUNTING AND DISMOUNTING OF HIP PACK ON WEARER.

2-54. MOUNTING.

2-55. To mount the hip pack and installed equipment, lift the hip pack by the shoulder straps, unbend the skirt plates just enough to permit sliding onto the body from the side. Place the shoulder straps so that they run down on each side of the wearer's neck and

swing the hip pack around for proper fit, with the front opening between the skirt plates centered with the waist of the wearer. Fasten the shoulder straps and then the waist straps. Pull buckles tight for comfortable fit.

2-56. DISMOUNTING.

2-57. To dismount the hip pack with installed equipment, unfasten waist strap first. Support hip pack on suitable table, bench or other natural elevation, or obtain help from another person. Release shoulder strap and proceed, following mounting procedure in reverse.