



NOTES:

1. UNLESS OTHERWISE SPECIFIED: RESISTANCE VALUES ARE IN OHMS AND 1/8 WATT.
2. CAPACITANCE VALUES ARE IN MICROFARADS.
3. PREFIX REFERENCE DESIGNATIONS OF ALL SWITCHES, CONTROLS AND INDICATORS WITH ASSEMBLY NUMBER A4.
4. SWITCH S1 IS SHOWN IN THE SEND POSITION.
5. INTERLOCK SWITCH S2 IS SHOWN IN THE OFF POSITION. SWITCH S2 AUTOMATICALLY COMES ON WHEN LID TO RADIO CASE IS OPENED.
6. FOR COLOR IDENTIFICATION OF WIRES FROM CONTACTS OF INTERLOCK SWITCH S2, SEE WIRING HARNESS DIAGRAM.

TM5820-552-15-42

Figure 7-27. Schematic diagram, top plate assembly A4, Radio Set AN/PRC-64A.